

Load Balancing Quantum ActiveScale

Version 1.0.0



Table of Contents

1. About this Brief	3
2. Loadbalancer.org Appliances Supported	3
3. Software Versions Supported	3
3.1. Loadbalancer.org Appliance	3
3.2. Quantum ActiveScale	3
4. Quantum ActiveScale	3
5. Load Balancing Quantum ActiveScale	3
5.1. Health Checks	3
6. Load Balancer Deployment Methods	4
6.1. 'Direct to Node' GSLB	4
7. Loadbalancer.org Appliance – the Basics	5
7.1. Virtual Appliance	5
7.2. Initial Network Configuration	5
7.3. Accessing the Appliance WebUI	5
7.3.1. Main Menu Options	7
7.4. Appliance Software Update	7
7.4.1. Online Update	7
7.4.2. Offline Update	8
7.5. Ports Used by the Appliance	8
7.6. HA Clustered Pair Configuration	9
8. Appliance Configuration for Quantum ActiveScale	9
8.1. Overview	9
8.2. Health Checks	10
8.3. Appliance Configuration	11
8.3.1. Step 1 – Configuring the Global Name	11
8.3.2. Step 2 – Configure the Members	11
8.3.3. Step 3 – Configure the Pool	12
8.3.4. Step 4 – Finalising the Configuration	13
8.4. DNS Server Configuration	13
8.5. Testing the Configuration	13
9. Testing & Verification	14
10. Technical Support	14
11. Further Documentation	14
12. Appendix	15
12.1. Microsoft DNS Server Configuration	15
12.1.1. Microsoft DNS Server	15
12.2. Configuring HA - Adding a Secondary Appliance	17
12.2.1. Non-Replicated Settings	17
12.2.2. Configuring the HA Clustered Pair	18
13. Document Revision History	21

1. About this Brief

This brief outlines the steps required to configure a load balanced Quantum ActiveScale environment utilizing Loadbalancer.org appliances. It covers the configuration of the load balancers and also any Quantum ActiveScale configuration changes that are required to enable load balancing.

For more information about initial appliance deployment, network configuration and using the Web User Interface (WebUI), please also refer to the [Administration Manual](#).

2. Loadbalancer.org Appliances Supported

All our products can be used with Quantum ActiveScale. For full specifications of available models please refer to <https://www.loadbalancer.org/products/enterprise>.

Some features may not be available or fully supported in all cloud platforms due to platform specific limitations. For more details, please refer to the "Main Differences to our Standard (Non-Cloud) Product" section in the appropriate cloud platform [Quick Start Guide](#) or check with Loadbalancer.org support.

3. Software Versions Supported

3.1. Loadbalancer.org Appliance

- V8.9.1 and later

Note

The screenshots used throughout this document aim to track the latest Loadbalancer.org software version. If you're using an older version, or the very latest, the screenshots presented here may not match your WebUI exactly.

3.2. Quantum ActiveScale

- All versions

4. Quantum ActiveScale

Quantum ActiveScale is an object storage solution which provides a new and innovative approach to creating a simple, 'always-on' data repository that scales when needed. This is done with the extreme data durability, accessibility, and security required of petabyte-scale growth. As part of this solution, ActiveScale Cold Storage reduces the cost of storing cold data sets by up to 80%.

5. Load Balancing Quantum ActiveScale

Note

It's highly recommended that you have a working Quantum ActiveScale environment first before implementing the load balancer.

5.1. Health Checks




GSLB-based health checks on port 443 are used to establish the health of the ActiveScale nodes.

6. Load Balancer Deployment Methods

For Quantum ActiveScale, using the somewhat uncommon "direct to node" GSLB deployment method is recommended. This mode is described below and is used for the configurations presented in this guide. For configuring using GSLB direct to node please refer to [Section 8, "Appliance Configuration for Quantum ActiveScale"](#).

6.1. 'Direct to Node' GSLB

- Round-robin DNS with health checking
- Client traffic flows directly to the ActiveScale Nodes and directly back again – the load balancer is entirely removed from the path of ActiveStore traffic
- Useful when network throughput is paramount while retaining the load balancer's active health checking of ActiveStore nodes



Note

The load balancer can be deployed as a single unit, although Loadbalancer.org recommends a clustered pair for resilience & high availability. Please refer to the section [Configuring HA - Adding a Secondary Appliance](#) in the appendix for more details on configuring a clustered pair.

A full explanation and instructions on setting up this type of deployment can be found in [Section 8, "Appliance](#)



7. Loadbalancer.org Appliance – the Basics

7.1. Virtual Appliance

A fully featured, fully supported 30 day trial is available if you are conducting a PoC (Proof of Concept) deployment. The VA is currently available for VMware, Virtual Box, Hyper-V, KVM, XEN and Nutanix AHV and has been optimized for each Hypervisor. By default, the VA is allocated 2 vCPUs, 4GB of RAM and has a 20GB virtual disk. The Virtual Appliance can be downloaded [here](#).

 **Note**

The same download is used for the licensed product, the only difference is that a license key file (supplied by our sales team when the product is purchased) must be applied using the appliance's WebUI.

 **Note**

Please refer to [Virtual Appliance Installation](#) and the ReadMe.txt text file included in the VA download for additional information on deploying the VA using the various Hypervisors.

 **Note**

The VA has 4 network adapters. For VMware only the first adapter (**eth0**) is connected by default. For HyperV, KVM, XEN and Nutanix AHV all adapters are disconnected by default. Use the network configuration screen within the Hypervisor to connect the required adapters.

7.2. Initial Network Configuration

After boot up, follow the instructions on the appliance console to configure the management IP address, subnet mask, default gateway, DNS servers and other network and administrative settings.

 **Important**

Be sure to set a secure password for the load balancer, when prompted during the setup routine.

7.3. Accessing the Appliance WebUI

The WebUI is accessed using a web browser. By default, users are authenticated using Apache authentication. Users can also be authenticated against LDAP, LDAPS, Active Directory or Radius - for more information, please refer to [External Authentication](#).

 **Note**

There are certain differences when accessing the WebUI for the cloud appliances. For details, please refer to the relevant [Quick Start / Configuration Guide](#).

1. Using a browser, navigate to the following URL:

<https://<IP-address-configured-during-the-network-setup-wizard>:9443/lbadmin/>

 **Note**

You'll receive a warning about the WebUI's SSL certificate. This is due to the default self signed certificate that is used. If preferred, you can upload your own certificate - for more information, please refer to [Appliance Security Features](#).



Note

If you need to change the port, IP address or protocol that the WebUI listens on, please refer to [Service Socket Addresses](#).

2. Log in to the WebUI using the following credentials:

Username: loadbalancer

Password: <configured-during-network-setup-wizard>

Note

To change the password, use the WebUI menu option: *Maintenance > Passwords*.

Once logged in, the WebUI will be displayed as shown below:

The screenshot shows the Loadbalancer Enterprise VA Max web interface. On the left is a navigation menu with items: System Overview, Local Configuration, Cluster Configuration, Maintenance, View Configuration, Reports, Logs, Support, and Live Chat. The main content area has a top bar with 'Primary | Secondary', 'Active | Passive', 'Link', and '8 Seconds'. A warning box states: 'WARNING: YOUR TRIAL IS DUE TO EXPIRE IN 30 DAYS. Buy with confidence. All purchases come with a 90 day money back guarantee. Already bought? Enter your license key here' with a 'Buy Now' button. Below is a 'System Overview' section with a question 'Would you like to run the Setup Wizard?' and 'Accept'/'Dismiss' buttons. A table below shows 'No Virtual Services configured.' with columns for VIRTUAL SERVICE, IP, PORTS, CONNS, PROTOCOL, METHOD, and MODE. Two graphs are visible: 'Network Bandwidth' and 'System Load Average'. The Network Bandwidth graph shows RX (red) and TX (blue) traffic in Bytes/s over time. The System Load Average graph shows 1m (red), 5m (green), and 15m (blue) averages. The Memory Usage graph is partially visible at the bottom.

3. You'll be asked if you want to run the Setup Wizard. Click **Dismiss** if you're following a guide or want to configure the appliance manually. Click **Accept** to start the Setup Wizard.



**Note**

The Setup Wizard can only be used to configure Layer 7 services.

7.3.1. Main Menu Options

System Overview - Displays a graphical summary of all VIPs, RIPs and key appliance statistics

Local Configuration - Configure local host settings such as IP address, DNS, system time etc.

Cluster Configuration - Configure load balanced services such as VIPs & RIPs

Maintenance - Perform maintenance tasks such as service restarts and creating backups

View Configuration - Display the saved appliance configuration settings

Reports - View various appliance reports & graphs

Logs - View various appliance logs

Support - Create a support download, contact the support team & access useful links

Live Chat - Start a live chat session with one of our Support Engineers

7.4. Appliance Software Update

We recommend that the appliance is kept up to date to ensure that you benefit from the latest bug fixes, security updates and feature improvements. Both online and offline update are supported.

**Note**

For full details, please refer to [Appliance Software Update](#) in the Administration Manual.

**Note**

Services may need to be restarted/reloaded after the update process completes or in some cases a full appliance restart may be required. We therefore recommend performing the update during a maintenance window.

7.4.1. Online Update

The appliance periodically contacts the Loadbalancer.org update server (update.loadbalancer.org) and checks for updates. This is the default behavior and can be disabled if preferred. If an update is found, a notification similar to the example below will be displayed at the top of the WebUI:

Information: Update 8.13.1 is now available for this appliance.

Online Update

Click **Online Update**. A summary of all new features, improvements, bug fixes and security updates included in the update will be displayed. Click **Update** at the bottom of the page to start the update process.

**Important**

Do not navigate away whilst the update is ongoing, this may cause the update to fail.

The update can take several minutes depending on download speed and upgrade version. Once complete, the following message will be displayed:



Information: Update completed successfully. Return to system overview.

If services need to be reloaded/restarted or the appliance needs a full restart, you'll be prompted accordingly.

7.4.2. Offline Update

If the appliance does not have access to the Internet, offline update can be used.

To check for the latest version, please refer to our product roadmap page available [here](#). To obtain the latest offline update files contact support@loadbalancer.org.

To perform an offline update:

1. Using the WebUI, navigate to: **Maintenance > Software Update**.
2. Select **Offline Update**.
3. The following screen will be displayed:

Software Update

Offline Update

The following steps will lead you through offline update.

1. Contact **Loadbalancer.org support** to obtain the offline update archive and checksum.
2. Save the archive and checksum to your local machine.
3. Select the archive and checksum files in the upload form below.
4. Click *Upload and Install* to begin the update process.

Archive: No file chosen

Checksum: No file chosen

4. Select the *Archive* and *Checksum* files.
5. Click **Upload and Install**.
6. If services need to be reloaded/restarted or the appliance needs a full restart, you'll be prompted accordingly.

7.5. Ports Used by the Appliance

By default, the appliance uses the following TCP & UDP ports:

Protocol	Port	Purpose
TCP	22 *	SSH
TCP & UDP	53 *	DNS / GSLB
TCP & UDP	123	NTP



Protocol	Port	Purpose
TCP & UDP	161 *	SNMP
UDP	6694	Heartbeat between Primary & Secondary appliances in HA mode
TCP	7778	HAProxy persistence table replication
TCP	9000 *	Gateway service (Centralized/Portal Management)
TCP	9080 *	WebUI - HTTP (disabled by default)
TCP	9081 *	Nginx fallback page
TCP	9443 *	WebUI - HTTPS
TCP	25565 *	Shuttle service (Centralized/Portal Management)

 **Note**

The ports used for SSH, GSLB, SNMP, the WebUI, the fallback page, the gateway service and the shuttle service can be changed if required. For more information, please refer to [Service Socket Addresses](#).

7.6. HA Clustered Pair Configuration

Loadbalancer.org recommend that load balancer appliances are deployed in pairs for high availability. In this guide a single unit is deployed first, adding a secondary unit is covered in the section [Configuring HA - Adding a Secondary Appliance](#) of the appendix.


8. Appliance Configuration for Quantum ActiveScale

8.1. Overview

In the context of a 'GSLB only', 'direct to node' configuration, the function of the load balancer is to ensure that connections to a Quantum ActiveScale cluster are distributed across the ActiveScale nodes. This is done to provide a highly available and scalable service. This is achieved by configuring the load balancers to actively health check the ActiveScale nodes and serve up the IP address of a healthy node in response to a (delegated) DNS request for the ActiveScale service's domain.

Deployment Example:





Explanation:

- **Start:** A client tries to access the S3 service by using the service's fully qualified domain name, in this example `s3-region1.domain.tld`
- The client sends a DNS query for `s3-region1.domain.tld` to the DNS server.
- The DNS server has a CNAME record for `s3-region1.domain.tld` which points to the domain `gslb.domain.tld`
- The DNS server has the domain `gslb.domain.tld` delegated to the load balancers.
- The DNS server sends a delegated DNS query for `gslb.domain.tld` to one of the load balancers.
- The load balancer that received the delegated DNS query replies to the DNS server. The load balancer answers with the IP address of a healthy, online ActiveScale node. In this example, `10.0.0.11` is the IP address returned by the load balancer.
- The DNS server sends the delegated DNS answer to the client.
- **Finish:** The client connects to the S3 service at `s3-region1.domain.tld` by using the IP address of the ActiveScale node that it was served.

8.2. Health Checks

The GSLB service, when configured as described in this section, polls each Quantum ActiveScale node at a regular interval to determine its health. This is achieved by checking that TCP port 443 is open.




8.3. Appliance Configuration

The GSLB service should be configured on the **primary** load balancer appliance.

Configuration takes place in the WebUI under *Cluster Configuration > GSLB Configuration*:

GSLB Configuration



Global Names Members Pools Topologies


No Data

New Global Name

8.3.1. Step 1 – Configuring the Global Name

1. Using the WebUI on the primary appliance, navigate to *Cluster Configuration > GSLB Configuration*.
2. Select the **Global Names** tab.
3. Click the **New Global Name** button.
4. Define a friendly *Name* for the new hostname, which can just be the subdomain itself, e.g. **quantum.example.com**
5. Define the *Hostname* of what will be the delegated subdomain, e.g. **quantum.example.com**
6. Click **Submit**.

GSLB Configuration



Global Names Members Pools Topologies

New Global Name

New Global Name

Name	<input type="text" value="quantum.example.com"/>	?
Hostname	<input type="text" value="quantum.example.com"/>	?
TTL	<input type="text" value="30"/> seconds	?

Submit Cancel

8.3.2. Step 2 – Configure the Members

Each *member* is a single ActiveScale node.

1. Select the **Members** tab.
2. Click the **New Member** button.
3. Enter a friendly *Name* for the member, e.g. **quantum-node1**.

- Specify an *IP* address for the member: in this context, this should be the IP address of the ActiveScale node in question, e.g. **10.0.0.11**.
- Ignore the example value in the *Monitor IP* field.
- Click **Submit**.
- Repeat these steps to add additional ActiveStore nodes as members as required.

GSLB Configuration

Global Names
Members
Pools
Topologies

New Member

New Member

Name	<input type="text" value="quantum-node1"/>	?
IP	<input type="text" value="10.0.0.11"/>	?
Monitor IP	<input type="text" value="10.2.0.1"/>	?
Weight	<input type="text" value="1"/> ▾	?

Submit
Cancel

8.3.3. Step 3 – Configure the Pool

A pool must be created to link together a global name with the members that should serve traffic for that global name.

Continuing with the example presented in this section, a pool would be created linking the global name `quantum.example.com` with the members (ActiveScale nodes), all of which should serve ActiveScale traffic.

- Select the **Pools** tab.
- Click the **New Pool** button.
- Enter a friendly *Name* for the pool, e.g. **quantum-nodes**.
- Set the *Monitor* to **TCP**.
- Set *Monitor Port* to **443**.
- Set *LB Method* to **wrr**.
- From the *Global Names* list box, select the global name in question, e.g. **quantum.example.com**
- In the *Members* section, drag the appropriate members (ActiveStore nodes) from the *Available Members* box into the *Members In Use* box.
- Click **Submit**.

New Pool

Name	<input type="text" value="quantum-nodes"/>	?				
Monitor	TCP	?				
Monitor Port	443	?				
Monitor Send String	check	?				
Monitor Match Return	up	?				
LB Method	wrr	?				
Global Names	quantum.example.com	?				
Members	<table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;">Available Members</td> <td style="width: 50%; border: none;">Members In Use</td> </tr> <tr> <td style="border: 1px solid #ccc; height: 100px;"></td> <td style="border: 1px solid #ccc; padding: 5px;"> <input type="text" value="quantum-node1"/> <input type="text" value="quantum-node2"/> </td> </tr> </table>	Available Members	Members In Use		<input type="text" value="quantum-node1"/> <input type="text" value="quantum-node2"/>	?
Available Members	Members In Use					
	<input type="text" value="quantum-node1"/> <input type="text" value="quantum-node2"/>					

8.3.4. Step 4 – Finalising the Configuration

To apply the new settings, the GSLB service must be restarted as follows:

- Using the WebUI, navigate to: *Maintenance > Restart Services* and click **Restart GSLB**.

8.4. DNS Server Configuration

Once the GSLB service has been configured on the primary load balancer the DNS server must then be configured for GSLB.

The DNS server must be configured to delegate DNS requests for the subdomain in question to the load balancers; the load balancers' GSLB services will serve the appropriate IP addresses to the DNS servers. Using the example presented throughout this section, the DNS server would be configured with a delegation for the domain quantum.example.com. The domain would be delegated to the load balancers.

Steps walking through creating a DNS delegation on a Microsoft DNS server in the context of setting up GSLB on our appliance can be found in the appendix, in the section [Microsoft DNS Server Configuration](#).

8.5. Testing the Configuration

The configuration can be tested to make sure it's working as expected.



From the command line on a Microsoft Windows machine, the *nslookup* program can be used to send test DNS queries to the load balancer(s). The primary load balancer is located at IP address 10.0.0.1 in the example presented here.

For the test, use the *-norecurse* option to instruct the load balancer **not** to attempt to query another server for the answer. A successful test would see the load balancer respond with the IP address of one of the online ActiveScale nodes, like so:

```
C:\Users\me>nslookup -norecurse quantum.example.com 10.0.0.1
Server: UnKnown
Address: 10.0.0.1

Name: quantum.example.com
Address: 10.0.0.11
```

9. Testing & Verification

Note

For additional guidance on diagnosing and resolving any issues you may have, please also refer to [Diagnostics & Troubleshooting](#).

10. Technical Support

For more details about configuring the appliance and assistance with designing your deployment please don't hesitate to contact the support team using the following email address: support@loadbalancer.org.

11. Further Documentation

For additional information, please refer to the [Administration Manual](#).



12. Appendix

12.1. Microsoft DNS Server Configuration

Once the GSLB service has been fully configured on the primary load balancer at every site, as described in the previous sections, the DNS server at each site must be configured for GSLB.


The DNS server at each site must be configured to delegate DNS requests for the subdomain in question to the load balancers; the load balancers' GSLB services will serve the appropriate IP addresses to the DNS servers. Using the example presented throughout this document, the DNS server at each site would be configured with a delegation for the domain `gslb.domain.tld`. The domain would be delegated to every load balancer across every site, which provides multi-site redundancy.

The exact steps for creating a DNS delegation vary between different DNS servers. Presented below are steps that walk through creating a DNS delegation on a Microsoft DNS server in the context of setting up GSLB on our appliance.

12.1.1. Microsoft DNS Server


Delegating a subdomain in Microsoft DNS Manager is a short process.

1. Open **DNS Manager** and create A records for every load balancer at every site, using **Action > New Host** (e.g. `dc1-lbprimary.domain.tld`, `dc1-lbsecondary.domain.tld`, `dc2-lbprimary.domain.tld`, and `dc2-lbsecondary`).



2. Provided that the load balancer part of the GSLB configuration has been completed and is working, the **New Delegation** wizard should now be used to delegate the subdomain to the load balancers. The delegation will use the new FQDNs for the load balancers, as defined in the previous step. The delegation wizard is located

at Action > New Delegation.



New Delegation Wizard


Delegated Domain Name
Authority for the DNS domain you supply will be delegated to a different zone.

Specify the name of the DNS domain you want to delegate.

Delegated domain:

Fully qualified domain name (FQDN):

< Back Next > Cancel



New Delegation Wizard

Name Servers
You can select one or more name servers to host the delegated zone.

Specify the names and IP addresses of the DNS servers you want to have host the delegated zone.

Name servers:

Server Fully Qualified Domain Name (FQDN)	IP Address
dc1-lbprimary.domain.tld.	[10.0.0.100]
dc1-lbsecondary.domain.tld.	[10.0.0.101]
dc2-lbprimary.domain.tld.	[172.16.0.100]
dc2-lbsecondary.domain.tld.	[172.16.0.101]

Add... Edit... Remove

< Back Next > Cancel

3. Test the delegation to make sure it is working as expected.

From the Windows command line, the `nslookup` program can be used to send test DNS queries to the DNS server. The DNS server is located at IP address 10.0.0.50 in the example presented here.

For the first test, use the `-norecurse` option to instruct the DNS server **not** to query another server for the answer. A successful test would see the DNS server respond and indicate that the subdomain in question is served by another server(s), giving the other server's details, like so:

```
C:\Users\me>nslookup -norecurse gslb.domain.tld 10.0.0.50
Server: UnKnown
Address: 10.0.0.50

Name:   gslb.domain.tld
Served by:
```



```

- dc1-lbprimary.domain.tld
  10.0.0.100
  gslb.domain.tld
- dc1-lbsecondary.domain.tld
  10.0.0.101
  gslb.domain.tld
- dc2-lbprimary.domain.tld
  172.16.0.100
  gslb.domain.tld
- dc2-lbsecondary.domain.tld
  172.16.0.101
  gslb.domain.tld

```

For the second test, execute the same command **without** the `-norecurse` option. This should see the DNS server fetch the answer from the load balancer and then serve up the 'fetched' answer in its response. A successful test would see the server reply with the IP address of one of the online sites/services, like so:

```

C:\Users\me>nslookup gslb.domain.tld 10.0.0.50
Server: UnKnown
Address: 10.0.0.50

Non-authoritative answer:
Name:   gslb.domain.tld
Address: 10.0.0.2

```

12.2. Configuring HA - Adding a Secondary Appliance

Our recommended configuration is to use a clustered HA pair of load balancers to provide a highly available and resilient load balancing solution. We recommend that the Primary appliance is fully configured first, then the Secondary appliance can be added to create an HA pair. Once the HA pair is configured, load balanced services must be configured and modified on the Primary appliance. The Secondary appliance will be automatically kept in sync.

Note

For Enterprise Azure, the HA pair should be configured first. For more information, please refer to the Azure Quick Start/Configuration Guide available in the [documentation library](#)

The clustered HA pair uses Heartbeat to determine the state of the other appliance. Should the active device (normally the Primary) suffer a failure, the passive device (normally the Secondary) will take over.

12.2.1. Non-Replicated Settings

A number of settings are not replicated as part of the Primary/Secondary pairing process and therefore must be manually configured on the Secondary appliance. These are listed by WebUI menu option in the table below:

WebUI Main Menu Option	Sub Menu Option	Description
Local Configuration	Hostname & DNS	Hostname and DNS settings
Local Configuration	Network Interface Configuration	Interface IP addresses, bonding configuration and VLANs



WebUI Main Menu Option	Sub Menu Option	Description
Local Configuration	Routing	Default gateways and static routes
Local Configuration	System Date & time	Time and date related settings
Local Configuration	Physical – Advanced Configuration	Various appliance settings
Local Configuration	Portal Management	Portal management settings
Local Configuration	Security	Security settings
Local Configuration	SNMP Configuration	SNMP settings
Local Configuration	Graphing	Graphing settings
Local Configuration	License Key	Appliance licensing
Maintenance	Backup & Restore	Local XML backups
Maintenance	Software Updates	Appliance software updates
Maintenance	Fallback Page	Fallback page configuration
Maintenance	Firewall Script	Firewall (iptables) configuration
Maintenance	Firewall Lockdown Wizard	Appliance management lockdown settings

(!) Important

Make sure that where any of the above have been configured on the Primary appliance, they're also configured on the Secondary.

12.2.2. Configuring the HA Clustered Pair

Note

If you have already run the firewall lockdown wizard on either appliance, you'll need to ensure that it is temporarily disabled on both appliances whilst performing the pairing process.

1. Deploy a second appliance that will be the Secondary and configure initial network settings.
2. Using the WebUI on the Primary appliance, navigate to: **Cluster Configuration > High-Availability Configuration**.

Create a Clustered Pair

LOADBALANCER

Local IP address
192.168.110.40

IP address of new peer
192.168.110.41

Password for *loadbalancer* user on peer
●●●●●●●●●●

Add new node

3. Specify the IP address and the *loadbalancer* user's password for the Secondary (peer) appliance as shown in the example above.
4. Click **Add new node**.
5. The pairing process now commences as shown below:

Create a Clustered Pair

LOADBALANCER Primary
IP: 192.168.110.40

Attempting to pair..

LOADBALANCER Secondary
IP: 192.168.110.41

Local IP address
192.168.110.40

IP address of new peer
192.168.110.41

Password for *loadbalancer* user on peer
●●●●●●●●●●

configuring

6. Once complete, the following will be displayed on the Primary appliance:

High Availability Configuration - primary

LOADBALANCER Primary
IP: 192.168.110.40

LOADBALANCER Secondary
IP: 192.168.110.41

Break Clustered Pair

7. To finalize the configuration, restart heartbeat and any other services as prompted in the "Commit changes" message box at the top of the screen.

 **Note**

Clicking the **Restart Heartbeat** button on the Primary appliance will also automatically restart heartbeat on the Secondary appliance.

 **Note**

For more details on configuring HA with 2 appliances, please refer to [Appliance Clustering for HA](#).

 **Note**

For details on testing and verifying HA, please refer to [Clustered Pair Diagnostics](#).

13. Document Revision History

Version	Date	Change	Reason for Change	Changed By
1.0.0	11 August 2023	Initial version		AH





Visit us: www.loadbalancer.org

Phone us: +44 (0)330 380 1064

Phone us: +1 833 274 2566

Email us: info@loadbalancer.org

Follow us: [@loadbalancer.org](https://twitter.com/loadbalancer.org)

About Loadbalancer.org

Loadbalancer.org's mission is to ensure that its clients' businesses are never interrupted. The load balancer experts ask the right questions to get to the heart of what matters, bringing a depth of understanding to each deployment. Experience enables Loadbalancer.org engineers to design less complex, unbreakable solutions - and to provide exceptional personalized support.

